

HaloTherapyPRO

Setup & Operating Instructions

Alternate Controller

Rev. October 2026

SYSTEM SETUP

System Setup

Step 1 - Unpack the Box

Carefully remove all items from the packaging.

You should have: • HaloTherapyPRO unit • Salt cover (salt lid) • Fan housing with fan installed • Power cord • 1 lb bag of HaloTherapy Salt

WARNING: If anything is missing or damaged, please contact HaloTherapyPRO customer support before use.

Step 2 - Position the HaloTherapyPRO

Place the unit in its designated location.

- Place the HaloTherapyPRO in its designated location, such as a booth, room, or tent.
- Set it on a stable, flat surface with adequate airflow around the unit.

Step 3 - Install the Fan Housing

Connect and seat the fan housing on top of the unit.

- Plug the fan into its connector on the HaloTherapyPRO, if it is not already connected.
- Insert the fan housing into the slot on top of the HaloTherapyPRO.

TIP: Make sure the fan label is facing forward — this indicates the correct direction of airflow.

Step 4 - Add the HaloTherapy Salt

Load the salt bowl with the included HaloTherapy Salt.

- Ensure the salt bowl is properly seated in the unit.
- Place the salt lid over the salt bowl.
- Add 1 teaspoon of the included HaloTherapy Salt.

Step 5 - Power On

Connect power and switch the unit on.

- Plug the included power cord into the HaloTherapyPRO.
- Plug the other end into a suitable wall outlet.
- Switch the unit on.

TIP: That's it — your HaloTherapyPRO is ready to use.

RUN TIME & PAUSE SETTINGS

Operating Cycle Information

Each device is tested and pre-programmed before shipping.

Your HaloTherapyPRO operates on the following pre-set cycle:

- 10 seconds ON
- 30 seconds OFF

Depending on the size of your booth, room, or tent, runtime may be adjusted at your discretion for the ideal session.

TIP: You can adjust the on/off cycle timing to suit the size of your space.

Recommended Settings

- Grind: 10 seconds
- Pause: 30 seconds

TIP: The Grind setting shown may be too high for smaller setups such as pop-up tents or compact salt spaces. Smaller enclosed areas can reach higher salt concentrations more quickly, so you may need to reduce the Grind time (RED) and/or increase the pause time (BLUE) to decrease salt output and find the setting that works best for your setup. Adjustments may vary depending on room size and preference.

Adjusting Time

Adjusting Grind & Pause Times

Change how long your HaloTherapyPRO Grinds and Pauses.

1. Press SET once. The red display (Grind Time) will flash.
2. Use the ▲ / ▼ buttons to set the desired run (grind) time.
3. Press SET again. The blue display (Pause Time) will flash.
4. Use the ▲ / ▼ buttons to set the desired pause time.
5. Wait 6 seconds. The settings will automatically save.

Video tutorial available at HaloTherapyPRO.com/setup

ALTERNATE CONTROLLER MODE SETUP

Settings to Adjust the Mode

These settings ensure the top timer controls the grind time (in seconds) and the bottom timer controls the pause time (in seconds).

These settings make the ****top timer control the grind time (in seconds)**** and the ****bottom timer control the pause time (in seconds).****

There are ****3 settings**** that need to be adjusted: ****P0, P1, and P2.****

****IMPORTANT:**** ****P0, P1, and P2** are the setting names shown on the top display. The top value does not change. Only change the value shown on the bottom display.******

Your settings should look like this:

****P0**** ← Top display — ****does not change****

****_0_**** ← Bottom display — set to ****_0_****

Sets the ****grind time**** to seconds.

****P1**** ← Top display — ****does not change****

****_0_**** ← Bottom display — set to ****_0_****

Sets the ****pause time**** to seconds.

****P2**** ← Top display — ****does not change****

****P-5**** ← Bottom display — set to ****P-5****

Sets the ****grind time to RED**** and the ****pause time to BLUE****.

How to Enter Settings Mode

****Press and hold SET for 3 seconds**** to enter the settings.

****IMPORTANT:**** If no button is pressed for ****6 seconds****, the controller will automatically save the settings and exit Settings Mode.



Step 1 - Set P0

****Set the bottom value to -0-. The P0 setting name on top will not change.****

1. ****Press and hold SET for 3 seconds**** to enter Settings Mode.
2. ****P0**** will appear on the ****top display****.
3. Use the ****▲ / ▼ buttons**** to change the ****bottom value**** to ****-0-****.
4. Confirm the display shows:

****P0**** ← Top

**** -0- **** ← Bottom

5. Press ****SET**** to continue to ****P1****.



Step 2 - Set P1

****Set the bottom value to -0-. The P1 setting name on top will not change.****

1. While still in ****Settings Mode****, press ****SET**** to move to ****P1****.
2. ****P1**** will appear on the ****top display****.
3. Use the ****▲ / ▼ buttons**** to change the ****bottom value**** to ****-0-****.
4. Confirm the display shows:

****P1**** ← Top

**** -0- **** ← Bottom

5. Press ****SET**** to continue to ****P2****.



Step 3 - Set P2

****Set the bottom value to P-5. The P2 setting name on top will not change.****

1. While still in ****Settings Mode****, press ****SET**** to move to ****P2****.
2. ****P2**** will appear on the ****top display****.
3. Use the ****▲ / ▼ buttons**** to change the ****bottom value**** to ****P-5****.
4. Confirm the display shows:

****P2**** ← Top

****P-5**** ← Bottom

5. ****Do not press anything.**** Wait about ****6 seconds**** for the controller to automatically save the settings and exit Settings Mode.



Support & Warranty

For additional information, customer support, or warranty claims, please visit www.HaloTherapyPRO.com. Thank you for choosing HaloTherapyPRO. Enjoy your halotherapy experience.